


Ergonomic desktop display mount installation instructions



Fits Most Monitors Size: 22"~32" Load Capacity: 4.4~26.4 lbs (2~12kg) VESA:75×75,100×100mm

Severe personal injury and property damage can result from improper installation or assembly.

- Read the following warning carefully before beginning.

 Products must be installed by professional or installer.
- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
 Do not install or assemble if the product or hardware is damaged or missing, if you
- require replacement parts, please contact you local distributor for assistance.

 This product fits most 22"-32" LCD / monitor; maximum weight of LCD / monitor:
- This product its most 22 32 CDD / monitor; maximum weight of LCD / monitor: 12 kg / 26.4 lbs.
 Installer-friendly and straight forward.
 For safe installation, the desk you are mounting to must support minimum 3 times the weight of the total load (the mount, the monitor and all accessories weight).
 Do not use this product for other than the original design.

- This product contain moving parts, please use with caution.
 When installing monitor, please do not damage electrical wiring or power source. Installation and routing of monitor cables on the monitor bracket must comply with
- Importantly, mains- and data-cables must be secured against twisting and squeezing or
- shearing.


 The manufacturer will bear no responsibility to the desk of mounting, or incidental or consequential damages arising thereof.

 The manufacturer disclaims any liability for the modifications, improper installation, or installation over the specified weight range. The manufacturer will not be liable for any damages arising out of the use of , or inability to use, the product.
- This product is designed for indoor use only, use of this product outdoor could lead to product failure and severe personal injury.


 A This product contains a high pressure gas spring, fire and percussion prohibited. Also it is
- strictly prohibited to dismantle without professionals. Please return to the manufacturer or hand over to professional agencies if the product is abandoned. In order to ensure the performance of gas spring, full direction adjustment of the product arm is recommended several times per month.

nbols			
<u> </u>	Tightening Direction loosening Direction	Ct/	+ : Torque increased - : Torque reduced
<u> </u>	拧紧方向 拧松方向	グジ	★ 定点恒力加大 Φ 定点恒力减小
G	Tightening Direction loosening Direction	1/	+ : Torque increased - : Torque reduced
	拧紧方向 拧松方向		★ 定点恒力加大 ● 定点恒力减小
	Phillips Screwdriver		By Hand
	螺丝起子		用手
S CH	Open-End Wrench		Hex Wrench
	开口扳手		六角扳手
+	Adjustment		Pencil
	调整		铅笔
OPT	Optional	NOTE	Reminder
	可选		提示
\triangle	Warning		Hand Drill
	警告		手电钻
×	Remove		Star Wrench
	移开		安全扳手
Δ	Beware	7	out or in
	提示		出或入


Part list




Adjustable Parameters




A1, Table Edge Installation




A2, Grommet Installation




B. Assembly support:




C, Rotation Restriction




D. Power and Display Lines Installation




E. Display Installation





F. Torque Adjustment


- "+": Torque increase direction shown fig-2
- " ": Torque decrease direction shown fig-2



Ensure display weight is within load range


- 1.If display can be hovered at any height after display installed.
- 2. If display lift up automatically after display installed, adjust as follow: Wind the set screw to '-' direction to reduce torque by using E, 5mm Alley key as shown in fig-E2 and G2. Until display can be hovered at any point of positions.
- 3.If display sit at lowest position, repeat #2 procedures but winding set screw to '+' direction to increase torque as fig-E2 and G2 until Display can be hovered at any point of

G, Display Adjustment



- #1: No adjustment is required when monitor stays static when tilting.
- #2: Adjust the screw as per illustrations above until monitor stays static at desired angle.

H、Display rotation



Only display comes with central gravity will has the best performance.

TENSION ADJUSTMENT AFTER MOUNT INSTALLED



Do not adjust tention without putting on display.

- 1. Ensure display has been put onto mount.
- 2.Read your display packaging or manual to find out display net weight.
- 3.Ensure display net weight between 4.4-26.4 lbs(2-12 kg)

Adjustment sign



Clockwise to Reduce tension (Carry less weight)

Anti-clockwise to Increase tension (Carry more weight)

Warning





KunshanHongjie Electronics Co., Ltd. 1050, FuChunJiangRoad, Economic Development Zone Kunshan City, Jiangsu Province. China. 215333

Mail: info@nbavmount.com

TEL: 86+512-57971777 FAX: 86+512-57970778

www.new-nb.com